



qSCALE maestro



Operator's Manual

NOTICE

SkyAzúl makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and/or its fitness for a particular purpose.

SkyAzúl will not be liable for errors contained in this manual or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual. This document contains proprietary information, which is protected by copyright, and all rights are reserved.

No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of SkyAzúl.

SkyAzúl reserves proprietary rights to all drawings, photos and the data contained therein. The drawings, photos and data are confidential and cannot be used or reproduced without the written consent of SkyAzúl. The drawings and/or photos are subject to technical modification without prior notice.

All information in this document is subject to change without notice.



SkyAzúl, Inc.
16 Walnut Street
Middletown, MD 21769
Fax 301-371-0029
info@skyazul.com

TABLE OF CONTENTS

1	Safety Instructions	6
1.1	EC Conformity Declaration	6
2	Product Description	7
2.1	Product Identification	8
2.2	Overview of Console Elements	9
2.3	Overview Feedback Elements	10
3	Operating Mode Selection	11
3.1	Switching Device On and Off	11
3.2	Setting the Operation Mode	13
4	Operation	16
4.1	Main Working Screen	17
4.1.1	Warning Lights / Audible Alarm	18
4.2	Work Area Limitations	19
4.2.1	Height Monitoring	21
4.2.2	Radius Monitoring	22
4.2.3	Boom Angle Monitoring	23
4.2.4	Wind Speed Monitoring	24
4.3	Tare Weight	26
4.4	Switching Off Audible Alarm	26
4.5	Error Events	27
4.6	Camera	29
5	Service and Maintenance	30
5.1	Settings Menu	30
5.2	Machine Information	31
5.2.1	System Version Information	31
5.2.2	Status of Digital Outputs	32
5.2.3	Status of Digital Inputs	33
5.2.4	Readings of Analog Sensors	34
5.3	User Screen	35
5.3.1	LCD Brightness	36
5.3.2	Key Brightness	37
5.3.3	Unit Selection	38
5.4	Sensor Calibration	39

5.5	System Information	40
5.6	Screen Capture	41
5.6.1	Taking Screen Captures	41
5.6.2	Saving Screen Captures	41
5.7	Maintenance and Repair	42
6	Appendix	43
6.1	Technical Data	43
6.2	Password Entry	44
6.3	Error Codes Table	45

Introduction

About this manual	This manual is a component of the equipment or systems supplied by WIKA Mobile Control LP. Keep this manual in a safe place and ensure that it is available to all users.
Liability disclaimer	The contents of this manual are subject to change. WIKA Mobile Control LP do not provide any guarantee for this material, including the associated guarantee regarding marketability and suitability for certain intended purposes. WIKA Mobile Control LP accept no liability for errors in the contents of the manual or for direct or indirect damage in connection with the provision and use of the manual.
Copyright notice	This manual is protected by copyright. All rights reserved. The manual may not be duplicated, reproduced or translated into another language, either wholly or partly, without the prior written permission of WIKA Mobile Control LP.
Trademarks	The rendition of common names, trade names, trademarks etc. in this documentation should not be construed to mean that such names, even without special identification, are free in the sense of trademark and trademark protection legislation and hence usable by anyone.
Use for the intended purpose	This device/system is intended exclusively for the tasks described in this manual. Any other use shall be construed as being inappropriate. The manufacturer accepts no liability for damage caused by inappropriate or impermissible use. This device / system may only be used if it is in perfect technical condition.
Qualification of the operating personnel	Only appropriately qualified personnel may work with this device / system, i.e. persons: ▪ who are familiar with the operation or installation and commissioning ▪ who know the current regulations for the prevention of accidents

HIRSCHMANN MCS

Marking of Notices

Dangers and other important notices are marked as follows in this user manual:



WARNING

Warning of direct threat of personal injury and damage to property.

Instructions on precautions to avert the danger.



CAUTION

Warning of dangerous situations. Also warns of damage to property.

Instructions for averting the danger.

IMPORTANT

Warning of possibly damaging situation for the product.

Instructions for avoiding the possibly damaging situation.



NOTE

Usage instructions and information, but no dangerous situation.



HINT

Supplementary comments and recommendations for the user.

1 Safety Instructions



WARNING

Imminent threat of personal injury and damage to property due to incorrect system settings!

The correct adjustment of the RCL to the current set-up status is essential for the correct function of the system and of the machine.

The RCL can only operate correctly if all settings are entered correctly according to the current set-up status during the **SETUP** procedure.

The settings can only be carried out by operators who are completely familiar with the operation and functions of the machine and the RCL.

The correctness of these settings must be guaranteed before starting the machine operations!

IMPORTANT

Connection to the wrong power supply will cause damage to the device.

The device may only be connected to a DC voltage source of 10 V to 30 V!

1.1 EC Conformity Declaration



The technical design and construction of the **qSCALE maestro** system corresponds to requirements of the EMC directive 2004/108/EC and therefore carries the CE symbol.

The device complies with the following standards:

EN 12895:200, EN 13309:2010, EN ISO 14982: 2009

The full conformity declaration is available from the manufacturer on request.

2 Product Description

The **vSCALE D2 maestro console** is the interface of the Rated Capacity Limiter system (RCL).

The RCL monitors the sensors and detects a machine overload status depending on various parameters.

The machine driver is warned before the onset of an overload status via visual and audible warning signals.

The RCL comprises:

- **qSCALE S6 maestro central control unit**
- **vSCALE D2 maestro console**
- various sensors for detection of machine status and environmental conditions

The **vSCALE D2 maestro console** is used for:

- programming and inputting operating parameters
- displaying the current machine operating data



NOTE

This user manual contains information about the **vSCALE D2 maestro console**, mode selection, operation, sensor calibration and maintenance.



WARNING

Although the system incorporates functions for monitoring adjustable geometrical limit values with visual and audible warnings and a relay output in the event of limit values being exceeded, the system cannot be used as an operational limit switch.


The machine driver is responsible for the safe operation of the machine.

2.1 Product Identification



The type plate carries the unique identification of the operating console. It is located on the back of the device.

Please ensure you make a note of all the information on your type plate for queries about this product.


Type plate
(Example for D2)



2.2 Overview of Console Elements



Function Keys F1 to F8: Calls Functions



Encoder With Pushbutton Function: For Selection and Confirmation



SET key: Selects Settings / Silences Alarm



HOME key: Returns to Main Working Screen



ESCAPE key: Aborts Function

2.3 Overview Feedback Elements



Light Sensor: Not Used



Operating Display: Green While Supply Voltage is Connected



USB Data Display: Yellow During Data Exchange via Front USB Port



Wireless Indicator: Not Used

Multi-Function Light:

	Flashes Red/White while in error state
	Blue while setting the operating mode
	Green while in operation
	Yellow Machine nearing operational limit

3 Operating Mode Selection

This chapter contains information, advice and instructions for choosing an operating mode.


3.1 Switching Device On and Off

The load limiting device has no on/off switch. The console automatically switches on with PTO power.

After boot-up, the following appears on the display:

Initial Display After
Boot-Up:

Operating Mode Selection Screen



If the machine configuration has not changed, check

displayed configurations. If OK, press

Then check outriggers and confirm with

The Main Working Screen is then displayed.

If the machine configuration has changed see Setting
Operation Mode in [Section 3.2](#)

System Malfunction? In the event of a system malfunction an error code is displayed in the bottom right of the display:



The error codes and what they mean are explained in the error codes table in [Section 6.3](#).

The device is not ready for operation until all faults have been rectified and no error codes are displayed. The error codes are displayed in red color. The warning codes are displayed in yellow color.



When confirming the operating mode, if the **vSCALE D2 maestro console** does not have a working Ethernet connection to the **qSCALE S6 maestro central control unit**, the operating mode will default to 0000 and error code 1F01 will be displayed.

The **vSCALE D2 maestro console** must be properly connected to the **qSCALE S6 maestro central control unit**, before confirming the operating mode. See the Service Manual for details.

3.2 Setting the Operation Mode

SETUP Procedure The RCL must be adjusted to the current machine setup status by completing the full SETUP procedure after start-up and after any change to the machine configuration.

The system is not ready to operate until the full SETUP procedure has been completed.



WARNING

Imminent threat of personal injury and damage to property due to incorrect system settings!

The correct adjustment of the RCL to the current set-up status is essential for the correct function of the system and of the machine.

The RCL can only operate correctly if all settings are entered correctly according to the current set-up status during the SETUP procedure.

The settings can only be carried out by operators who are completely familiar with the operation and functions of the machine and the RCL.

The correctness of these settings must be guaranteed before operating the machine!

Operating Mode Depending on the inputs during the SETUP procedure and on various sensor values, the determines the corresponding operating mode with the associated lifting capacity table. The operating mode used by the system at any given time is displayed as a code in the status row:



Process The process for setting the RCL to the current machine status (SETUP procedure) includes the following steps:

- Entering Operating Mode selection screen from the Main Working Screen or automatically after the console is powered on.
- Entering the number of rope reeving.
- Selection of the hoist used.
- Selecting the operating mode that matches the current outrigger and jib status.
- Overview of inputs




NOTE

The process for setting the RCL to the current set-up status (SETUP procedure) will vary by machine model. The following is an example machine.

Selection


Selection is with the rotary control:



Optionally press “up arrow”  or “down arrow”  function keys to select options.


Start SETUP

Operating Mode Setup can be called from the main RCL operating menu by pressing the  function key.

Select Reeving

Selection:


- Press the  button to enter the Select Reeving Menu.
- When the Reeving Button turns green  you can adjust the Reeving value.
- Use rotary knob or up and down arrows to select reeving amount.

Select Hoist

Selection:

- Press the  button to enter the Select Hoist Menu.
- When the Hoist Button turns green  you can adjust the Hoist option.
- Use rotary knob or up and down arrows to select Hoist.

Select Operating Mode



Selection:

- Press the  button to enter the Operating Mode Menu.
- When the Operating Mode Button turns green  you can adjust the Operating Mode number.
- Use rotary knob or up and down arrows to select the operating mode that corresponds to the current machine setup. Ensuring that the Jib and Outriggers match the description shown on the right.

Confirm Selections



After selecting the appropriate modes

press  or  to set the selected operating mode.

Check that the outriggers are in the correct position for the selected mode and that the machine is stable

and press  or .

The selected mode, reeving and hoist will be displayed.

Press  or  again to confirm the settings are accurate and return to the Main Working Screen using the newly selected operating mode.

4 Operation

After the operating mode is set, the RCL is ready to use.

The machine operator must be familiar with all operating elements of the RCL before operating the machine.

All settings must be checked by hoisting a known load and comparing the information with that displayed by the RCL.



WARNING

Imminent threat of personal injury and damage to property due to incorrect system settings!

The correct adjustment of the RCL to the current set-up status is essential for the correct function of the system.

The correctness of these settings must be guaranteed before operating the machine!

4.1 Main Working Screen

The RCL Main Working Screen is the central operating image during machine operation and the starting point for the selection of various functions. You can return to this screen from any other screen by pressing the “Home” button. 



Other indicators such as Jib Length and Jib Angle may be displayed on the Main Operating Screen and can be set up in the Settings Menu.

Function Keys



Settings
(see [Section 5.1](#))



Set or Disable Tare
(see [Section 4.3](#))



Camera
(see [Section 4.6](#))



Set Operating Mode
(see [Section 3.2](#))



Work Area Limitations
(see [Section 4.2](#))



Temporarily Mute Alarm (And after muting, display warnings. See [Section 4.4](#))



Function keys with no assigned symbol are not active:

4.1.1 Warning Lights / Audible Alarm

Various warning symbols are shown in the information bar as required and are visible from any screen:



Depending on the cause of the warning the following also occurs:

- audible alarm is activated
- error code is displayed (see error table in appendix)
- status is recorded in the data logger

Acknowledging Alarm

The audible alarm can be suppressed for a short period by pressing the  function key. See [Section 4.4](#) for more detail.



Early overload warning

This yellow symbol flashes to indicate that the machine load is or has already exceeded 90% of the safe working load. An overload status may be imminent!



Overload/Error

This red symbol is lit to indicate that an error has occurred such as the maximum machine load has been reached or exceeded.

The audible alarm sounds an uninterrupted tone.



RCL bypass

These red symbols flash on and off during the manual override of the power-off function of the safe load indicator. This status is recorded in the data logger. An audible alarm will be triggered and may be muted by

the  function key. (See [Section 4.4](#) for more detail.)



Stroke End (A2B)

This red symbol lights up to indicate that a two-block event has occurred.

A stroke end status is recorded if the load block comes into contact with the boom head. There is a danger in this case that the lifting rope will break and the load will drop. A stroke end state can be caused by the load being pulled against the boom head or the boom being extended or raised without playing out the lifting rope. The audible alarm sounds an uninterrupted tone.

4.2 Work Area Limitations

The RCL system has programmable functions for monitoring geometrical limits of the working area:

- Height Monitoring > See [Section 4.2.1](#)
- Radius Monitoring > See [Section 4.2.2](#)
- Boom Angle Monitoring > See [Section 4.2.3](#)
- Wind Speed Monitoring > See [Section 4.2.4](#)

Programming is carried out via an interactive menu.

The functions can be set individually or in combination. Active limit values are indicated by the display of color-highlighted symbols.

Exceeding a programmed limit value causes a corresponding color change in the limit symbol on the main menu to be displayed and an audible alarm warning to be sounded.

Color Meanings



Blue No Limits Set



Green Within Valid Limits




Yellow Warning Condition / Approaching Limit



Red Outside Limit

**CAUTION**

Machine movements are not switched off when limit values are exceeded.

**Function Keys**

Angle Limit
(see [Section 4.2.3](#))



Wind Speed Limit
(see [Section 4.2.4](#))



Radius Limit
(see [Section 4.2.2](#))



Deactivate all Limits



Height Monitoring
(see [Section 4.2.1](#))

The colors of the function buttons and symbols will change depending on the state of the limit.

Color Meanings:

- Limit inactive or not programmed
- Limit active
- Limit Nearing Maximum Value
- Limit value reached or exceeded





4.2.1 Height Monitoring

Boom Height Limit is able to be programmed.




HOME



LIMITS



HEIGHT



Current Height

Saved Limit Value

Function
Keys



Save Current Boom Head Height as
Limit Value



Return to Limit Menu



Turn On/Off Height Limit



4.2.2 Radius Monitoring

Upper and Lower Radius Limits are able to be programmed.



HOME




LIMITS



RADIUS

Saved Limit Value of
Minimum Radius
(Activated)



Current Radius

Saved Limit Value of
Maximum Radius

Function
Keys



Save Current Radius as Maximum
Radius Limit



Save Current Radius as Minimum
Radius Limit



Turn On/Off Maximum Radius Limit



Turn On/Off Minimum Radius Limit



Return to Limit Menu



4.2.3 Boom Angle Monitoring

Upper and Lower Boom Angle Limits are able to be programmed




HOME



LIMITS



BOOM
ANGLE



Function
Keys



Save Current Radius as Maximum
Angle Limit



Save Current Radius as Minimum
Angle Limit



Turn On/Off Maximum Angle Limit



Turn On/Off Minimum Angle Limit



Return to Limit Menu



4.2.4 Wind Speed Monitoring

Maximum safe operating Wind Speed can be programmed




HOME



LIMITS



WIND
SPEED



Current Measured Wind
Speed

Wind Speed Limit Set

Function
Keys



Sets Upper Wind Speed Limit (see
instructions, below)



Turn On/Off Maximum Wind Speed
Limit



Return to Limit Menu


Instructions



1. Press

Use the rotary knob to select the numbers.
Pressing the knob moves to the next digit and selects right arrow.

Pressing the right arrow when the cursor is to the right of the last number confirms the entry




2. Press the  button to add a decimal point.

3. Use the  button to change the input between a negative or positive value.

4. Use the  or  buttons to select the number in the chosen direction. (The selected digit turns green.)

5. Use the  button to delete the currently selected digit.

6. Press  to confirm the wind speed limit as entered.





4.3 Tare Weight

This function key is used to remove the weight of the hoisting gear and load block from the displayed load..

Pressing this button sets the load value to zero in order to subsequently display only the weight of the load and not the lifting apparatus.

The tare is removed when the operating mode changes, the length or angle of the boom changes, or



NOTE

The current load includes the weight of the load block, the lifting rope and all load-slinging attachments.

The net load is the actual load on the hook without load-slinging attachments.

Environmental influences can lead to incorrect displays (e.g. wind affecting the boom or load).



4.4 Switching Off Audible Alarm

When an error event occurs, the silence function button on the Main Working Screen will turn green and pressing it will suppress the audible alarm for 5 minutes.



Pressing the "SET" function key will also suppress the audible alarms.





4.5 Error Events




Pressing the “Silence” function button will momentarily display the “Error Event” function button. Pressing the “Error Event” function button will bring up the Error Event Page, which displays error specific information.



If the Alarm is already muted the “Silence” button will be greyed out but will still display the “Error Event” button if pressed.



Error Event Page Example



Use the Rotary Knob

or the “Left Arrow”



and “Right Arrow”




function keys to scroll through the errors.

Press the "HOME"  or "ESCAPE"  key to return to the RCL Main Working Screen.



4.6 Camera

If an external camera is installed it can be viewed from the console by pressing the  button.



Function
Keys



Rotates Camera Display



Maximizes or Minimizes Camera display



Return to Main Working Screen

5 Service and Maintenance

5.1 Settings Menu



System settings can be found under the Settings Menu.



HOME



SETTINGS



Daily Password Seed.
See service manual for
details.

Function
Keys



Sensor Calibration
(See [Section 5.4](#))



System Information
(See [Section 5.5](#))



System Settings
(See Service Manual)



Machine Information Screen
(See [Section 5.2](#))



User Screen
(See [Section 5.3](#))



5.2 Machine Information

The Machine Information Screen shows the Machine Model, Machine Serial Number as well as Digital Outputs, Analog Inputs, and Digital Inputs.



HOME



SETTINGS



MACHINE
INFO

5.2.1 System Version Information



HOME



SETTINGS



MACHINE
INFO



VERSION
INFO

The System Version Information Screen shows the Machine Serial Number, Operating System and Software Versions.



5.2.2 Status of Digital Outputs



The system Digital Output Information is displayed here. See the Service Manual for more detail.



HOME



SETTINGS



MACHINE
INFO




DIGITAL
OUTPUTS

If Green, Output is 'High'
If Red, Output is 'Low'



Digital Output Status



Use the Rotary Knob

or the "Up Arrow"



and "Down Arrow"



function keys to scroll through the list of outputs.



5.2.3 Status of Digital Inputs

The system Digital Input Information is displayed here. See the Service Manual for more detail.



HOME



SETTINGS




MACHINE
INFO



DIGITAL
INPUTS

If Green, Input is 'High'
If Red, Input is 'Low'



Use the Rotary Knob

or the "Up Arrow"



and "Down Arrow"



function keys to scroll through the list of inputs.

5.2.4 Readings of Analog Sensors



Readings of the analog sensors can be called up. See the Service Manual for more Detail.



HOME



SETTINGS



MACHINE
INFO




ANALOG
INPUTS

Raw Sensor Data



Scaled Value



Use the Rotary Knob
through the list of inputs.

or the "Up Arrow"



and "Down Arrow"



function keys to scroll



5.3 User Screen

Alarm volume, display brightness, key brightness, and measurement units can be selected in the User Screen.




HOME



SETTINGS



USER SCREEN



Function
Keys



Alarm Volume
(See Service Manual)



LCD Screen Brightness
(See [Section 5.3.1](#))



Key Brightness
(See [Section 5.3.2](#))




Unit Selection
(See [Section 5.3.3](#))




5.3.1 LCD Brightness

The LCD Screen brightness can be adjusted in the User Screen.



Use the rotary knob to adjust the brightness.


Pressing the knob or  to confirm.






5.3.2 Key Brightness

The Brightness of the Keys on the console can be adjusted in the User Screen.



Use the rotary knob to adjust the brightness.

Pressing the knob or  to confirm.





5.3.3 Unit Selection

The measurement units can be switched between US and SI units.



HOME




SETTINGS



USER SCREEN



UNIT
SELECTION



Press the  key to switch units. The key will change to show the current selection:



For SI Units



For US Units



5.4 Sensor Calibration

The sensors must be calibrated before operation after installation.




HOME



SETTINGS



SENSOR
CALIBRATION



Function
Keys



Angle Sensor Calibration
(See Service Manual)



Length Sensor Calibration
(See Service Manual)




Luffing Cylinder Tuning
(See Service Manual)

Function Keys may vary by machine model depending on the sensors being used.



5.5 System Information

From the System Information screen you can set the Date and Time, view and reset the runtime of the system, rotate the display, download the event recorder data, and download updates from the USB.



Function
Keys



Download application data
from USB
(See Service Manual)



Log debug data to USB
(See Service Manual)



Change Date and Time
(See Service Manual)



Reset System Runtime
(See Service Manual)



Rotate Display
(See Service Manual)

5.6 Screen Capture

The system has the capability of taking screenshots and saved to either:

1. USB Drive
2. Internal Memory

5.6.1 Taking Screen Captures

On any screen:

- Press and hold the “HOME”  function button
- Press the “SET”  function button
- Release both the “HOME” and “SET” function buttons simultaneously
- A screen shot of the current screen will be saved.

5.6.2 Saving Screen Captures

If a USB drive is installed in the console, the screen capture will be saved to the USB drive.

If a USB drive is **not** installed in the console, the image will be saved to the internal memory of the console.

If using internal memory, only 20 images may be saved. After 20 images are saved, additional screen captures will not be saved. The saved images can be transferred to a USB drive. This is done by:

1. Installing a USB drive
2. Take a new screenshot.
Once a screenshot is taken the images in internal memory are copied to the USB drive and removed from internal memory.

5.7 Maintenance and Repair

Maintenance The **qSCALE S6 maestro central control unit** and **vSCALE D2 maestro console** contain no wearing parts and therefore cannot be opened. If you notice malfunctions or differences between actual and displayed measured values, you should switch the device off and have it checked and, if necessary, repaired immediately by an authorized WIKA service partner.

Cleaning Clean the surface and the front screen of the device occasionally with a damp cloth and a mild detergent. Never use abrasive or aggressive detergents as these may damage the device.

IMPORTANT

Device may be damaged by the use of high-pressure cleaners.

The device must not be treated with a high-pressure cleaner or similarly aggressive method under any circumstances!

Usage Condensation inside the vSCALE D2 maestro console can damage electronic components or the LCD and can condense at the inner side of the front glass/touch. Although the vSCALE D2 maestro console is designed as a closed housing with a Gore-Tex-Membrane for breathing, condensation may occur as a physical effect, if the console is exposed to unfavorable temperature/humidity cycles, which pumps humidity inside the housing.

Repair Damage to the front foil can lead to the penetration of moisture and dirt into the interior of the device, which must then be properly repaired without delay.

Keep the contacts and the area around the device connectors clean and check occasionally that all connections are secure.

If parts are damaged, they must be properly repaired or replaced immediately.


6 Appendix

This appendix contains additional technical information and the full table of error codes.

6.1 Technical Data

Operating voltage	9...36 V DC, suitable for 12 and/or 24 V on-board power supply
Overvoltage protection	overvoltage up to max. 48V DC / 2 minutes
Reverse polarity protection	up to -48V DC
Display	4.3" TFT Color Graphic LCD, 480 x 272 Pixel (WVGA)
Brightness	400 cd/m ²
Contrast	400:1 or 500:1
Illumination	LED, adjustable brightness
Audible alarm	built-in, output for external horn
Dimensions	See Service Manual
Operating temperature range	-40°C to +75°C
Protection class	IP66 and IP67 according to ISO 20653: Road Vehicles – Degrees of protection (IP-Code) – Protection of electrical equipment against foreign objects, water and access
Scope of supply	- vSCALE D2 maestro console (depending on scope of delivery with pre-fitted bracket for RAM Mount) - Mount articulated mounting - User manual (PDF file or on data storage device)

6.2 Password Entry




Password entry is done by the following instructions:

Use the rotary knob to select the numbers.

Pressing the knob moves to the next digit and selects right arrow.

Pressing the right arrow when the cursor is to the right of the last number confirms the entry.



Use the  or  buttons to select the number in the chosen direction. (The selected digit turns green and will be replaced by the next selection.) Use the  button to delete the currently selected digit.

Press  to confirm the password as displayed.

6.3 Error Codes Table

The first one or two digits of an error code can determine what type of error is occurring

00xx	General Error	Other
2xxx		Module Error
3xxx		Module Error
1Fxx		System
01xx	Limiter Error	Global Cut
02xx		Single Cut
03xx		Error
04xx		Warning
05xx		Pre-Warning
0Axx	Kinematic Error	Kinematic
0Bxx		Kinematic
11xx	Parameter Errors	Cable Break / Lower Limit
12xx		Short-Circuit to Ground
13xx		Short-Circuit / Upper Limit
14xx		Module Error
15xx		Output Deactivated
16xx		Sensor Supply Voltage Error
17xx		Data Error / CAN Error
18xx		Timeout / CAN Timeout
19xx		Safety Error
1Axx		Parameter Error
1Bxx		Unspecified Error

Error Code	Description	Solution
Limiter Errors 0100 – 05FF		
E0100	Min radius limit underrun (global cut)	Boom down to a valid load-chart radius and angle
E0101	Max radius limit exceeded (global cut)	Boom up to a valid load-chart radius and angle
E0102	Main boom angle too low (global cut)	Boom up to a valid load-chart radius and angle
E0103	Main boom angle too high (global cut)	Boom down to a valid load-chart radius and angle
E0104	Jib angle limit underrun (global cut)	Move the jib up to a load chart permissible radius or angle
E0105	Jib angle limit exceeded (global cut)	Move the jib down to a load chart permissible radius or angle
E010A	Slew angle left to large (global cut)	Return to the permitted Working Range (load chart)
E010B	Slew angle right to large (global cut)	Return to the permitted Working Range (load chart)
E010C	Min length limit underrun (global cut)	Telescope into the permitted Working Range (load chart)
E010D	Max length limit exceeded (global cut)	Telescope into the permitted Working Range (load chart)
E010E	Min height limit underrun (global cut)	Move the boom into the permitted Working Range (load chart)
E010F	Max height limit exceeded (global cut)	Move the boom into the permitted Working Range (load chart)
E012D	Max length limit exceeded (global cut)	Telescope into the permitted Working Range (load chart)
E0140	Min radius limit underrun (global cut)	Move the Jib down to a valid radius and angle
E0141	Max radius limit exceeded (global cut)	Boom up to a valid radius and angle
E0142	Main boom angle too low (global cut)	Boom up to a valid radius and angle
E0143	Main boom angle too high (global cut)	Move the Jib down to a valid radius and angle
E0144	Jib angle limit underrun (global cut)	Move the jib up to a valid radius or angle
E0145	Jib angle limit exceeded (global cut)	Move the jib down to a valid radius or angle
E0146	Jib angle limit underrun (global cut)	Move the jib up to a valid radius or angle
E0147	Jib angle limit exceeded (global cut)	Move the jib down to a valid radius or angle
E014A	Slew angle left to large (global cut)	Rotate to the permitted Working Range
E014B	Slew angle right to large (global cut)	Rotate to the permitted Working Range
E014C	Min length limit underrun (global cut)	Telescope into the permitted Working Range
E014D	Max length limit exceeded (global cut)	Telescope into the permitted Working Range
E014E	Min height limit underrun (global cut)	Move the boom into the permitted Working Range (load chart)
E014F	Max height limit exceeded (global cut)	Move the boom into the permitted Working Range
E0150	Min wind speed limit underrun (global cut)	Operation is restricted to permitted conditions
E0151	Max wind speed limit exceeded (global cut)	Operation is restricted to permitted conditions
E0411	Max wind speed limit exceeded (Warning)	Operation is restricted to permitted conditions (load chart)

Error Code	Description	Solution
Kinematic Errors 0A00 – 0AFF		
E0A00	Capacity utilization >= 100%	Lay down the load. Only operate within allowed parameters
E0A08	Capacity utilization >= 90%	Warning: Operating close to Cut-off
E0A20	Shutdown due to overload	Lay down the load. Only operate within allowed parameters
E0A21	Overload Warning	Warning: Operating close to Cut-off
E0A24	A2B switch	Lower the load
E0A33	System Bypass	Warning: Load monitoring inactive
E0A35	Bypass A2B switch	Warning: Load Lift not monitored

Error Code	Description	Solution
Sensor & I/O Errors 1100 – 1BFF		
E1X00	Sensor Error: IOLength1	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X01	Sensor Error: IOAngle1	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X02	Sensor Error: IOPiston1	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X03	Sensor Error: IORod1	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X04	Sensor Error: IOLength2	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X05	Sensor Error: IOAngle2	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X06	Sensor Error: IOPiston2	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X07	Sensor Error: IORod2	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X18	Sensor Error: IOInput1	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X19	Sensor Error: IOInput2	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X1A	Sensor Error: IOInput3	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X1B	Sensor Error: IOInput4	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X1C	Sensor Error: IOInput5	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X1D	Sensor Error: IOInput6	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X1E	Sensor Error: IOInput7	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X1F	Sensor Error: IOInput8	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X20	Sensor Error: IOForce1	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X21	Sensor Error: IOForce2	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X28	Sensor Error: IOSlew1	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X2C	Sensor Error: IOMAngle1	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X2D	Sensor Error: IOMAngle2	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X2E	Sensor Error: IOMAngle3	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X2F	Sensor Error: IOMAngle4	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor

Error Code	Description	Solution
E1X34	Sensor Error: IOWind1	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X38	Sensor Error: IOIncX1	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X39	Sensor Error: IOIncY1	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X3C	Sensor Error: IOMaxA2B1	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X44	Sensor Error: IOCutByp1	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X61	Actuator Error: IOCut	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X63	Actuator Error: IORigging	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X6C	Actuator Error: IOLampGreen	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X6D	Actuator Error: IOLampYellow	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X6E	Actuator Error: IOLampRed	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X7E	Actuator Error: IOOutput1	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X7F	Actuator Error: IOOutput2	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor
E1X80	Actuator Error: IOOutput3	Check the CAN connections and wiring, the sensor calibration, and the CAN configuration. Replace faulty sensor

Error Code	Description	Solution
General Errors		
E0090	Operating mode changed	Not Available
E00FC	Controller Not Initialized	The error will clear when the system finishes the initialization process
E1F00	System Error	Turn the Ignition off and on again. Consult Customer Service if the error occurs again
E1F01	Timeout	Check the bus cabling or connector. Try turning the Ignition off and on again. Consult Customer Service if the error occurs again
E1F02	Timeout	Turn the Ignition off and on again. Consult Customer Service if the error occurs again
E1F03	Timeout	Turn the Ignition off and on again. Consult Customer Service if the error occurs again
E1F04	Timeout	Turn the Ignition off and on again. Consult Customer Service if the error occurs again
E1F05	Timeout	Turn the Ignition off and on again. Consult Customer Service if the error occurs again
E1F06	Timeout	Turn the Ignition off and on again. Consult Customer Service if the error occurs again
E1F07	Timeout	Turn the Ignition off and on again. Consult Customer Service if the error occurs again
E1F10	Computer operation error	Turn the Ignition off and on again. Consult Customer Service if the error occurs again
E1F18	Serial Number wrong or not set	Set Serial Number to valid entry
E1F1F	Outputs deactivated	Information: Subsequent errors resulting from another system error
E1F2F	Outputs deactivated	Information: Subsequent errors resulting from another system error
E1F41	Battery voltage	Call Customer Service to have the unit replaced
E1F44	CAN bus network error	Check the CAN cabling and supply voltage. Try turning the Ignition off and on again. Consult Customer Service if the error occurs again
E1F4F	Version Error	Call Customer Service to have the unit or software replaced
E2001	Module Error	Turn the Ignition off and on again. Consult Customer Service if the error occurs again
E2005	Module Error	Turn the Ignition off and on again. Consult Customer Service if the error occurs again
E2015	Module Error	Select a valid Operating Mode
E3001	Module Error	Turn the Ignition off and on again. Consult Customer Service if the error occurs again



www.skyazul.com

SkyAzúl, Inc.
16 Walnut Street
Middletown, MD 21769
Phone 301-371-6126
Fax 301-371-0029
info@skyazul.com